

PROFLOW™ CLEANING PARTS AND CARE INSTRUCTIONS


Washing Cleaning

Warm, Cold & Soapy Water




OR

Soda Water



Refreshing corks


After long periods of use



The fins on the cork may form to the shape of the bottle neck



Hot water



The fins will return to original state



WARNING: DO NOT PLACE ANY PART IN A GLASSWASHER, DISHWASHER OR BOILING WATER